








Form:
style
Dekor:
design




New Baroque
New Baroque
Light Blue Glaze 15













PAOLANAVONE
PER
REICHENBACH

Kaffee- und Tafelgeschirr
Tee- und Moccageschirr
Geschenkartikel

Artikelbezeichnung	
	Kaffeekanne/ Coffee pot 0,90 l 024004 1,30 l 024002 1,75 l 024001
	Teekanne/ Tea pot 0,60 l 024203 1,20 l 024202
	Zuckerdose/ Sugar bowl 0,15 l 024306 0,25 l 024302 0,40 l 024301
	Tasse fl. m. Untertasse Cup-saucer flat 0,10 l 026401 0,22 l 026407
	Obertasse flach/ Cup flat 0,10 l 024605 0,22 l 024602
	Untertasse / Saucer 11 cm 025304 15,5 cm 025302
	Platte oval Platter oval 32 cm 022402 38 cm 022401
	Platte rund flach Platter round flat 30 cm 022202
	Teller tief/ Plate deep 22 cm 020104

	Salzstreuer Salt castor 0,03 l 021807
	Pfefferstreuer Peppercastor 0,03 l 021806
	Merrettichdose Horse-radish pot 0,25 l 021804

Artikelbezeichnung	
	Tasse hoch m. Untertasse Cup-saucer high 0,10 l 026402 0,20 l 026406
	Obertasse hoch/ Cup high 0,10 l 024705 0,20 l 024703
	Untertasse / Saucer 11 cm 025304 15,5 cm 025302
	Suppentasse m. Untertasse Soup c/s 0,30 l 026420
	Suppenobertasse Soup-cup 0,30 l 024601
	Suppenuntertasse Soup-saucer 17 cm 025301
	Gießer/ Creamer 0,15 l 024406 0,30 l 024403 0,40 l 024402
	Salatieren rund Saladbowl round 23 cm 020602 27 cm 020601
	Obstschale Fruitbowl 31 cm 022805
	Tortenplatte flach Cake plate flat 19 cm 022804 24 cm 022803 27 cm 022802 30 cm 022801
	Teller flach/ Plate flat 17 cm 020006 19 cm 020005 23,5 cm 020003 26 cm 020002
	Terrine Souptureen 2,30 l 021004 3,35 l 021001
	Senfgefäß Mustardpot 0,12 l 021805
	Beilagschale oval Pickle dish oval 23 cm 022404